

Using Wireless IR Mic (Handheld / Tie-clip)

Handheld Mic:

1. Insert two AA batteries into the handheld mic tube for proper operation. (Fig. 1)
2. Place the batteries into the mic tube in the correct **+ positive** and **- negative** directions.
3. Securely tighten the mic cover.
4. Turn on the power of the microphone. (Fig. 2)



Fig. 1 Handheld Mic components



Fig. 2 Handheld Mic Power ON

Tie-clip Mic:

1. Connect the Tie-clip mic jack to the IR bodypack transmitter. (Fig. 3)
2. Place two AA batteries into IR bodypack transmitter in the correct **+ positive** and **- negative** directions.
3. Securely insert the mic cover.
4. Switch to **B Channel** and Turn on the power of the microphone. (Fig. 4)
5. Adjust the side wheel to the appropriate volume.



Fig. 3 Tie-clip Mic components



Fig. 4 Tie-clip Mic Power ON